


Aktivace terminálu DX8000



Steps to change payment terminal:

ENSURE YOU ARE CONNECTED TO WIFI: **FESTIVAL_5G**

1. Deactivate the device and use a pin code. 260089 At the Blue Launcher settings or Nastaveni
2. Send us a list of Serial Number and device number, Such as:
3. - 26: 2456MD8V3287
- 27: 2456MD8V3451
- 28: 2414MD8J1891
4. Wait for our changes - send us a message.
5. Once you receive the QR from us, scan it within 5mins - ensure you scan on the correct device as is the name on the screenshot
6. Open IngenicoPay3k -> Hamburger menu -> Settings (Nastaveni) - Heslo: 360063
7. Konfigurace terminalu -> Inicializace terminalu -> Confirm: Optavdu si prejete stahnout konfiguraci z portalu -> OK
8. Open the app again, v Nastaveni -> Konfigurace terminalu -> Stahnutie TMK
9. Enter following into the form:
10. TMK:

FTP URL: 193.33.23.55
FTP Port: 7926
FTP Meno: PG008Bxxxx (same like the TID in the top of the screen)
FTP heslo: truxxxx1

Revision #5

Created 2025-04-16 05:05:40 UTC by Tomáš Fikar

Updated 2026-03-25 08:43:46 UTC by Admin